

Technical data sheet: P-support

P-support is a thermoplastic polymer specially developed for 3D printing of polypropylene (PP), which fulfils all the functions of a "breakaway" support material. It has very good adherence to PP and can be easily removed from the finished part after heating to about 100°C without leaving residues.

Material description

Trade name	P-support
Manufacturer	PPprint GmbH
Polymer group	Thermoplastic polymer
Chemical name	Polyolefin
Use	Extrusion-based 3D printing

Suggested 3D print settings (nozzle diameter 0.4mm)

Nozzle temperature	200 - 220 °C
Bed temperature	20 °C (50 - 80 °C recommended for the first layer, 100 – 110 °C for non-destructive removal after completion)
Chamber temperature	not required
Bed modification	P-surface 141
Active fan cooling	recommended
Layer height	0.1 – 0.4 mm
Print speed	15 – 40 mm/s

Removal of P-support from the printed part

P-support adheres very strongly to the printed PP part in 3D printed state. To remove P-support, the printed part must be heated to 100 - 110°C. A conventional heating oven can be used for this purpose. It is also possible to use a boiling water bath for heating. At approx. 100°C P-support becomes "chewing gum-like" soft and formable. P-support can be removed immediately when hot or after cooling it can be pulled down using a little more force.

Material properties

Melt temperature	90-100 °C	-
Melt Flow Rate ¹	15.4 g/10 min	ISO 1133
Melt Volume Rate ¹	15.7 cm ³ /10 min	ISO 1133
Density	0.98 g/cm ³	-
Odor	odorless	-
Color	natural	-

¹ Test conditions: T = 210 °C; m = 5.0 kg

Adherence of P-support to with P-filament printed parts

Tensile test	For the investigation, dog bones were manufactured standing upright in accordance with DIN EN ISO 527 using extrusion-based 3D printing. In the narrow parallel middle section, three alternating layers, composed each of five layers of P-support and five layers of P-filament, were printed in the middle. Under tensile load, the dog bone breaks at the P-filament/P-support interface.
E-Modul (MPa)	450 ± 30
Strain at break (%)	0.5 ± 0.2

Mechanical properties: Tensile test

All specimens were punched out of printed square tubes consisting of two shells, which were 3D printed with a Raise3D Pro2 3D printer and applying the following printing conditions:

Nozzle temperature: 210 ° C
 Bed temperature: 70 ° C
 Chamber temperature: 70 ° C
 Print speed: 30 mm/s
 Layer height: 0.2 mm



punched dog bone: S 3A with an orientation of 90 ° to the nozzle movement direction



punched dog bone: S 3A with an orientation of 0 ° to the nozzle movement direction

E-Modul (MPa)	505 ± 40	1200 ± 250
Yield strength (MPa)	11.9 ± 1.3	33.5 ± 1.3
Tensile strength (MPa)	12.0 ± 1.3	26.0 ± 5.8
Strain at break (%)	16.4 ± 6	158 ± 90

Certifications/ approvals*

Regulation EU Nr. 10/2011	Union Guidelines on Regulation (EU) No 10/2011 on plastic materials and articles intended to come into contact with food (Europe)
FDA	Food and Drug administration approval (USA)

* These data are generated using information obtained from the raw material suppliers.

Filament specification

Diameter 1.75	1.75 ± 0.10 mm	PPprint
Diameter 2.85	2.85 ± 0.10 mm	PPprint
Ovality	0.05	PPprint
Netto weight on spool	600 g ± 5%	PPprint



Annotation

The data and properties presented here are averages of a standard batch. The 3D printed square tubes from which the specimens were punched out were produced in Slic3r version 1.3.0.

Disclaimer

Acceptance of any technical information or assistance contained herein is at your own risk. PPprint GmbH makes no warranty with respect to or based on this information. PPprint GmbH is not liable for the use of this information or the mentioned products, processes or devices. It is your sole responsibility to determine their suitability and completeness for your individual application, for the protection of the environment as well as for the health and safety of your employees and buyers of your products. PPprint GmbH makes no warranty as to the marketability or suitability of the products and nothing herein constitutes a waiver of PPprint's Terms of Sale. Specifications are subject to change without notice.

Version: 1.001

Date: 22.11.2020